


LT 5005

Spare parts list

Rammer

LT 5005



General information

This spare parts list applies to the following:

Part number	Description
967869704	Rammer LT 5005 150 mm, (6 in.). Standard
967869703	Rammer LT 5005 150 mm, (6 in.). With air filter indicator
967869701	Rammer LT 5005 230 mm, (9 in.). Standard
967869702	Rammer LT 5005 230 mm, (9 in.). With air filter indicator

Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability. Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.

Instructions for use

This spare parts list contains no safety regulations and is merely intended to assist in the ordering of spare parts.

For information about operating, servicing, or repairing, the relevant Safety and operating instructions must be consulted at all costs.

Please observe the safety instructions listed in the relevant Safety and operating instructions!

Kits and consumables	1
----------------------	---

Preventative Maintenance Kits

Start Up Kit	3
Six months / Every 100 hours kit	5

Service, repair and wear part kits

Shock absorber repair kit	7
Transmission repair kit	9
Spring unit repair kit	11
Extended foot kit	13
Foot 230 mm (9 in.) repair kit	15
Foot 150 mm (6 in.) repair kit	17
Air filter indicator and hour meter kit	19
Trolley	21
Repair kit, Bellows	23

Spare parts list

Handle and covers	25
Throttle control and fuel system	27
Air filter and engine installation	30
Engine, Honda GXR120	33
Transmission	35
Extended foot	37
Spring unit	39
Foot 150 mm (6 in.)	41
Foot 230 mm (9 in.)	43
Labels	45

Kits and consumables

Service offers resume LT5005	Item	Description
Preventive Maintenance	1	One year service kit
Wear&Repair Kits	2	Bellow repair kit
	3	Foot 150 mm (6 in) repair kit
	4	Foot 230 mm (9 in) repair kit
	5	Shock absorber repair kit
	6	Repair kit, spring unit
	7	Repair kit, transmission

Item	Part No.	Name	Qty	L
1	594211201	One year service kit	1	
2	595383801	Bellow repair kit	1	
3	594213201	Foot 150 mm (6 in) repair kit	1	
4	594213401	Foot 230 mm (9 in) repair kit	1	
5	594211301	Shock absorber repair kit	1	
6	594657101	Repair kit, spring unit	1	
7	594655101	Repair kit, transmission	1	

Preventative Maintenance Kits Start Up Kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

Item	Part No.	Name	Qty	L
1	594216501	Start Up Kit	1	
2	594214501	Six months / Every 100 hours kit	1	
3	594180401	Fuel Filter	2	
4	594168701	Air filter, complete	3	

Preventative Maintenance Kits Six months / Every 100 hours kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

Item	Part No.	Name	Qty	L
2	594214501	Six months / Every 100 hours kit	1	
3	594180401	Fuel Filter	2	
4	594168701	Air filter, complete	3	

Service, repair and wear part kits Shock absorber repair kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

Item	Part No.	Name	Qty	L
1	594211301	Shock absorber repair kit	1	
2	594167001	Shock absorber	2	
3	595348301	Screw	4	
4	595036601	Plain washer(a) 8.4 x 16 x 1.6	4	
5	595034501	Hex. Sock. Screw	4	

Service, repair and wear part kits Transmission repair kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM


Item	Part No.	Name	Qty	L
1	594655101	Repair kit, transmission	1	
2	594537401	Needle roller bearing	1	
3	594258501	Ball Bearing	1	
4	595144401	Circlip ring	1	
5	594537301	Needle roller bearing	1	
6	595045601	Snap ring	2	
7	594531701	Ball Bearing	2	
8	595353501	Internal circlip	2	
9	594537601	Sealing	1	
10	-	Nut	1	
11	595355201	O-ring	1	
12	-	Screw	4	
13	595117701	O-Ring	1	
14	-	Washer	4	
15	-	Screw	4	
16	-	Washer	1	
17	-	Screw	1	

Service, repair and wear part kits Spring unit repair kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

Item	Part No.	Name	Qty	L
1	594657101	Repair kit, spring unit	1	
2	594461301	Spring	1	
3	594461201	Spring	1	
4	594461801	Stop	1	
5	594461701	Stop	1	
6	-	Screw, M8 x 50 mm 8.8 A2K	6	
7	594462301	Gasket	1	
8	595047001	O-ring	1	
9	595047701	Seal ring	1	
10	-	Washer, 27 x 32 x 2 mm, 1.06 x 1.26 x 0.08 in.	1	

Service, repair and wear part kits Extended foot kit



Item	Part No.	Name	Qty	L
1	594823701	Extended foot kit	1	
2	-	Foot	1	
3	-	Screw, M12 x 90 mm 10.9 GEOMET®	2	A
4	-	Screw, M12 x 70 mm 10.9 GEOMET®	2	A
5	-	Nut, M12	4	
6	-	Washer, 13 x 24 x 2 mm, 0.51 x 0.98 x 0.08 in. 300 HV	4	
7	-	Instruction label	1	B

Service, repair and wear part kits Foot 230 mm (9 in.) repair kit


Image does not exist

Item	Part No.	Name	Qty	L
1	594609801	Foot kit, cpl	1	
2	595175001	Ground plate	1	
3	594462201	Foot	1	
4	594514301	Screw, M12 x 100 mm 10.9 GEOMET®	2	A
5	594517201	Screw, M12 x 150 mm 10.9 GEOMET®	2	A
6	-	Washer, 8.4 x 22 x 3 mm, 0.33 x 0.87 x 0.12 in. HV300	8	
7	-	Nut, M8 x 1.25 mm A2K	8	
8	594517001	Screw, M8 x 50 mm NYLOK BLUE PATCH™(Known as TUF-LOK® in Europe)	8	B
9	-	Nut, M8 x 1.25 mm A2K	4	

Service, repair and wear part kits Foot 150 mm (6 in.) repair kit


NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

Item	Part No.	Name	Qty	L
1	594609601	Foot kit, cpl	1	
2	594462001	Ground plate	1	
3	594461901	Foot	1	
4	594514301	Screw, M12 x 100 mm 10.9 GEOMET®	2	A
5	594517201	Screw, M12 x 150 mm 10.9 GEOMET®	2	A
6	-	Washer, 8.4 x 22 x 3 mm, 0.33 x 0.87 x 0.12 in. HV300	4	
7	-	Nut, M8 x 1.25 mm A2K	4	
8	594517001	Screw, M8 x 50 mm NYLOK BLUE PATCH™(Known as TUF-LOK® in Europe)	4	B
9	-	Nut, M8 x 1.25 mm A2K	4	


Service, repair and wear part kits Air filter indicator and hour meter kit

Item	Part No.	Name	Qty	L
1	595363801	Indicator and hour meter kit	1	

Service, repair and wear part kits Trolley




Item	Part No.	Name	Qty	L
1	595519401	Trolley	1	


Service, repair and wear part kits Repair kit, Bellows

Item	Part No.	Name	Qty	L
1	594120301	Hex sock. screw	2	
2	594490301	Hose clamp	1	
3	594490401	Hose clamp	1	
4	594651901	Bellow	1	

Spare parts list Handle and covers



Item	Part No.	Name	Qty	L
1	594167101	Handle	1	
2	595276101	Hood, complete	1	
3	594192101	Hood knob	1	
4	-	Hood	1	
5	595036001	Nut	4	
6	594458501	Roller	2	
7	595348301	Screw	12	
8	595111201	Screw, M6x30, 8.8	4	
9	594167301	Rear cover	1	
10	595034501	Hex. Sock. Screw	4	
11	595348101	Hex sock. screw	4	
12	595034201	Screw	16	
13	594959401	Engine cover	1	
14	594167401	Right side cover	1	
15	595036501	Plain washer	4	
16	595036601	Plain washer(a) 8.4 x 16 x 1.6	12	
17	594174501	Handle bracket	1	
18	-	Air filter housing	1	A
19	594167001	Shock absorber	2	
20	594167501	Left side cover	1	
21	595035701	Hexagon nut	4	
22	594181501	Distance sleeve	4	

Spare parts list Throttle control and fuel system


Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	594210901	Fuel tank, complete	1	
2	594169901	Fuel cap	1	
3	-	Fuel tank	1	
4	594212101	Fuel hose kit	1	
5	-	Fuel hose	1	
6	-	Fuel hose	1	
7	-	Fuel hose	1	
8	-	Fuel hose	1	
9	594180401	Fuel Filter	1	
10	594211701	Throttle control, complete	1	
11	594169601	Throttle wire, complete	1	
12	594169701	Throttle lever	1	
14	-	Locknut	1	
17	-	Screw M6 x 20 mm 8.8 A2K	1	
18	594211001	Cable harness, complete	1	
19	-	Cable harness	1	
21	594181601	End cover	1	
22	594178201	Fuel tap ON/OFF wire	1	
23	-	Screw M6 x 20 mm 8.8 A2K	1	
24	594125401	Pipe clamp	1	
25	-	Nut	1	
26	594211101	Fuel tap, complete	1	
27	-	Fuel tap screw	1	
28	595043901	Lock washer	2	
29	594127701	Hexagon nut m8	2	
30	-	Fuel tap	1	
31	594127701	Hexagon nut m8	1	
32	595111001	Screw	2	
33	594123801	Plain washer	2	
34	594121301	Screw, M5 x 12 mm	2	
35	594125601	Pipe clamp	2	
36	594119601	Screw, M6 x 20 mm	1	
38	595036501	Plain washer	4	
39	595036001	Nut	4	
40	594125801	Hose clamp	6	
41	595111201	Screw, M6x30, 8.8	1	
42	594119601	Screw, M6 x 20 mm	4	
43	594177701	Bracket	1	

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.


Item	Part No.	Name	Qty	L
44	594126001	Cable tie	1	
45	595374701	Socket	1	
46	-	Nipple	1	
47	595355901	Shrinking hose	1	
48	594169501	Reglage switch	1	

This page intentionally left blank

Spare parts list Air filter and engine installation


Item	Part No.	Name	Qty	L
1	594168701	Air filter, complete	1	
2	594168001	Air filter housing, complete	1	
3	594179001	Gasket	1	
4	-	Air filter housing	1	
5	594169101	Evacuator valve	2	
6	594192201	Handle bracket	1	
7	595363701	Holder	1	
8	594178301	Air filter indicator, complete	1	
9	594171401	Hose	1	
10	594171301	Connection	1	
11	594171201	Washer	1	
12	594171101	Fitting	1	
13	594171501	Air filter indicator	1	
14	595111101	Screw, M6 x 14 mm	3	
15	594169201	Hour meter	1	
16	594121701	Screw, RXK PHIL ST 2.9 x 6.5 mm	2	
17	595043901	Lock washer	4	
18	595348301	Screw	4	
19	595348101	Hex sock. screw	4	
20	594177101	Engine oil indicator, complete	1	
21	-	Wiring harness	1	
22	-	Nut	1	
23	594125901	Hose clamp	2	
24	594168301	Air intake hose	1	
25	594168101	Air hose connection	1	
26	594437601	Hose	1	
27	594122701	Nut, M12 x 1.25 mm A3K	1	
28	594161701	Centrifugal clutch, complete	1	
29	595375801	Engine adapter	1	
30	595463801	Stud, M10 x 47 mm	4	
31	595035501	Nut, fine pitch, M10 x 1.25 mm	4	
32	594177001	Engine, complete Honda GXR120RT KRD6	1	
33	595036501	Plain washer	3	
34	594460001	Key	1	

Spare parts list Engine, Honda GXR120




Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	594177001	Engine, complete Honda GXR120RT KRD6	1	
2	--	Engine	1	
3	594189901	Pump primer	1	
4	594191201	Cover, head	1	
5	594191301	Bolt, flange, 6x14 (ct200)	1	
6	595374201	Oil dipstick gasket	1	
7	595374301	Oil Dipstick CPL	1	
8	594190601	Plug, spark (cr5hsb)	1	
9	595048901	Oil plug gasket	1	
10	595374401	Oil plug	1	
11	595372401	Gasket, muffler	1	
12	595129001	Cover	1	
13	595372301	Muffler	1	
14	594213801	carburettor	1	
27	594189801	Spacer, recoil starter mounting	1	
15	594215601	Recoil starter complete	1	
16	594190201	Handle	1	
17	594190301	Rope, recoil starter	1	
18	594190001	Cover black	1	
19	594190501	Plate, slide	1	
20	594190101	Spring	1	
21	594190401	Plate, side	1	
22	595371801	Reel	1	
23	595371901	Ratchet, starter	2	
24	595372001	Guide, ratchet	1	
25	595372101	Spring, friction	1	
26	595372201	Screw, setting	1	


Spare parts list Transmission

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.


Item	Part No.	Name	Qty	L
1	594442101	Gear wheel	1	
2	594537401	Needle roller bearing	1	
3	594442201	Connecting rod	1	
4	594258501	Ball Bearing	1	
5	594124701	Circlip	1	
6	594537301	Needle roller bearing	1	
7	595114001	Circlip	2	
8	594531701	Ball Bearing	2	
9	595046201	Retaining ring	2	
10	594537601	Sealing	1	
11	594444001	Shaft	1	
12	594166901	Crankcase	1	
13	595047201	O-ring	1	
14	595362901	Cover	1	
15	595179801	Hexagon socket head cap screw	4	
16	594501701	Pin	1	
17	595046901	O-ring	1	
18	595066701	plain washer	4	
19	595058301	screw M 6	4	
20	594488501	Outer tube	1	

Spare parts list Extended foot

Item	Part No.	Name	Qty	L
1	594477001	Extended foot	1	
2	594532401	Screw, M12 x 70 mm 10.9 GEOMET®	2	
3	594546401	Screw, M12 x 90 mm 10.9 GEOMET®	2	A
4	-	Nut, M12 x 1.75 mm	4	
5	-	Washer, 3 x 24 x 2 mm, 0.51 x 0.98 x 0.08 in. 300 HV	4	


Spare parts list Spring unit

Item	Part No.	Name	Qty	L
1	594444101	Piston bolt	1	
2	595052201	Plug	2	
3	594461401	Piston head	1	
4	594459901	Cover	1	
5	594461301	Spring	2	
6	594461201	Spring	2	
7	594461801	Stop	1	
8	594461501	Piston rod	1	
9	594461701	Stop	1	
10	594490401	Hose clamp	1	
11	594546301	Screw	4	
12	594651901	Bellow	1	
13	594490301	Hose clamp	1	
14	594459701	Bellows support	1	
15	594518501	Sight plug	1	
16	594462301	Gasket	1	
17	594459801	Inner tube	1	
18	595174901	Cover	1	
19	594537501	Plug	1	
20	595047001	O-ring	1	
21	595057601	Screw, M8 x 50 mm 8.8 A2K	6	
22	595047701	Seal ring	6	
23	594518401	Fiber washer	1	
24	595052301	Grab handle	1	
25	594123301	Nut, M12, 10.9	2	
26	594760001	Foot	1	
27	594193501	Foot	1	

Spare parts list Foot 150 mm (6 in.)


Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	594461901	Foot	1	
2	594168501	Ground plate 150 mm, 6 in.	1	
3	594122201	Screw, M12 x 100 mm, 10.9, DIN608	2	A
4	594122401	Screw, M12 x 150 mm, 10.9, DIN608	2	A
5	594517001	Screw, M8 x 50 mm NYLOK BLUE PATCH™(Known as TUF-LOK® in Europe)	4	B
6	594123201	Nut	8	
7	-	Washer, 8.4 x 22 x 3 mm, 0.33 x 0.87 x 0.12 in. HV300	8	

Spare parts list Foot 230 mm (9 in.)

Item	Part No.	Name	Qty	L
1	594462201	Foot	1	
2	594168601	Ground plate, 230 mm, 9 in.	1	
3	594122201	Screw, M12 x 100 mm, 10.9, DIN608	2	A
4	594122401	Screw, M12 x 150 mm, 10.9, DIN608	2	A
5	594517001	Screw, M8 x 50 mm NYLOK BLUE PATCH™(Known as TUF-LOK® in Europe)	8	B
6	-	Nut, M8 x 1.25 mm	8	
7	-	Washer, 8.4 x 22 x 3 mm, 0.33 x 0.87 x 0.12 in. HV300	7	
8	594123201	Nut	4	

Spare parts list Labels



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	594661401	Label, start instruction	1	
2	594659901	Label, lifting point	2	
3	594660001	Label, air filter indicator	1	
4	594659801	Safety label, hot surfaces	1	
5	-	Data plate (not available separately)	1	
6	-	Rivet	2	
7	594660201	Label, fuel	1	
8	594660101	Label, start instruction	1	
9	594661101	Label, engine choke and primer pump	1	
10	594754801	Product label "LT 5005"	2	
11	594514401	Safety label, compressed spring package	1	
12	594661301	Label, engine oil indicator	1	
13	594659601	Safety label, read instructions, ear protection and safety boots	1	
14	-	Sound power label	1	
15	594170301	Information label, emission control information	1	
16	595376001	Product label	1	

Any unauthorized use or copying of the contents or any part thereof is prohibited.
This applies in particular to trademarks, model denominations, part numbers, and
drawings.